

# Loss Control Insights Safety with Hot Liquid Asphalt

For properly maintained roads, streets, and highways, hot liquid asphalt material must be applied at one point or another. Although methods will vary, the procedures for applying asphalt have one thing in common: the asphalt products must be heated to a prescribed temperature to perform well.

Because transferring, heating, and applying these products can be dangerous, caution and awareness of



safety must be kept foremost in an applicator's mind. Most applications of hot liquid asphalts involve either distributor trucks or crack-seal machines. Safety tips for both will be covered in this tech sheet. Keep in mind that your greatest allies when it comes to ensuring safety are a deliberate approach to operating the equipment and an awareness of what those around you are doing.

# Personnel Safety

The high temperatures at which asphalt products must be applied demand that equipment operators and crew members wear personal protective equipment

### (PPE).

The driver of a distributor truck is unlikely to come in contact with hot asphalt during the application process when he is seated safely behind the wheel. However, a driver faces a greater risk to be burned when refilling the truck or unclogging plugged nozzles. At a minimum, the driver should wear a hardhat, face shield, leather gloves, and a long-sleeved shirt.

During crack-sealing operations, the operator of the wand, squeegee operators, and anyone else working in close proximity to the hot asphalt must wear the correct PPE— must wear head protection with solid face shield attached, apron, long-sleeved shirt, safety glasses, and leather gloves where danger of spraying or splashing of hot liquid could cause injury from burns.

# **Material Safety**

Identify the safe heating temperature range and "flash point" of the materials. safe heating temperature is the temperature range in which the material can be properly applied to the roadway. Flash point is the temperature at which the material will ignite if oxygen and an ignition source are present.

The flash point of a given material is determined by performing a test, called the Cleveland Open Cup method, in which the material is heated to the temperature at which it will produce a flash when an ignition source is passed over it. Material safe heating temperatures and flash points can be found on the Safety Data Sheet (SDS) that accompany the materials shipped from the manufacturer. Additionally, this information is printed on the boxes the material is shipped in.

# Equipment Safety

Read and fully understand the operator's manuals before operating any equipment that carries, heats, or dispenses liquid asphalt.

- Never substitute "after-market" parts for original equipment- manufactured parts without first consulting the
  manufacturer. Going to the local auto parts store for rubber hoses for the crack-seal machine could be a
  costly and dangerous practice. Not all rubber hoses are compatible with the unique ingredients or high
  application temperatures of some asphalt material. A rupture of a hose under pressure of hot asphalt is
  hazardous to the operator and to anyone near or passing by the equipment.
- Know the proper procedure for adding more material to the equipment. Before opening access lids, determine whether or not circulation pumps should be on, burners and engines should be shut down, and auger systems should be turned off. All of these and more are important to safe operation.

Optimus Risk Services / 3862 Grove Road / Gibsonia, PA / 15044 / Phone: 724.444.4580/ Fax: 724.444.4581 / Website: optimusrisk.com

• Keep a fully charged fire extinguisher rated for burning oil readily available at the worksite.

#### Safety Around Distributor Truck

Know the proper temperature range of the asphalt products you plan to apply prior to heating them. Proper heating is determined with a working thermometer on the distributor truck. Overheating the asphalt not only endangers workers, but it destroys the good properties of the asphalt, and the product will not perform satisfactorily.

Never try to unplug a nozzle with the system pressurized. Even if you're successful, you are risking one or more workers getting burned when the plugged material comes out of the nozzle under pressure at somewhere between 30 and 70 pounds per square inch.

Always wear eye, ear, and face protection and protective clothing for the body when doing any maintenance on the plumbing system of the equipment. Ideally, the material it contains will be cold and not at operating temperature, but in real life this will not always be the case. The personal protective equipment should be designed to protect the wearer from getting burned.

### First Aid Tips

Always have an adequate supply of cold water and first-aid kits on or near the crack-seal machine.

If a worker is burned with hot asphalt, seek medical attention immediately. The National Asphalt Pavement Association suggests applying cold water, not ice, to the burned area. **Do not remove** the asphalt from the burn victim; let medical personnel do it.

#### Safety with Crack-Seal Machines

Another piece of equipment commonly used in the application of hot asphalt is the crack-seal machine. A number of manufacturers produce this equipment, but most machines fall into one of two basic design types: direct-heat and double- wall with heat-transfer oil.

Direct-heat units use a flame to heat a metal plate at the bottom of the tank. The other design, a double-wall unit, consists of an inner tank surrounded by heat-transferring oil, which is used to heat the asphalt for crack sealant that is in the inner tank.

Here are some safety practices while working with crack-seal machines:

- Make sure the operator is familiar with the equipment and fully trained in its operation.
- Never heat the material in an enclosed area. Always park the equipment outside before lighting.
- Be aware of pinch points, and keep hands, feet, and clothing away from all moving parts.
- Follow the instructions for startup and shutdown of burners and pilot lights.
- Replace any hoses that show excessive wear, are fraying, or feel as if they may split. Be sure all fittings and joints are tight.
- Make sure all auger and agitator systems have stopped completely before opening the lid to the material compartment to add new material.
- In the event of material overflow or spillage, immediately shut off burners and other flame sources to prevent a fire.
- Do not mix different ISO grades of heat-transfer oil. Different heat-transfer oils expand at different temperatures.
- Do not mix different crack-sealing materials without first checking with the supplier.
- Do not add kerosene or diesel fuel to crack-sealing materials.
- Never exceed the manufacturer's heating and application temperatures for the crack-sealing material.
- Follow the equipment manufacturer's recommendation for cleaning and flushing of equipment, hoses, etc.

- Do not apply heat (for example, from a torch) directly to any wand, hose, or other part except where authorized by the manufacturer.
- Make sure operators of the sealant wand are wearing a heavy-duty face shield.
- Remove a clogged hose or wand from service until cleared by boiling or other manufacturerapproved method.

This information is intended to increase your awareness of the hazards of working with hot asphalts and provide precautions that you can take to reduce or eliminate the chances that you or one of your co-workers will become a burn victim.

Source: PennDot Tech Information Sheet 178